

# HOME PLUMBING STRUCTURED WATER STEP BY STEP

## for the Shower

### IMPORTANT

All the illustrations in this instruction show typical plumbing methods; actual installations must be adapted to individual requirements and regional codes. The author has made every effort to ensure accuracy and reliability of the information, instructions, and directions. However, neither the author nor the manufacture will accept responsibility for misinterpretation of the directions or human error.

### **NOTE: Structured Water**

1. Is not designed for extended hot water use above 140 degrees.
2. Is not designed to sustain freezing temperatures with residue water inside; function will possibly be deteriorated.
3. The unit you received may rattle, this is normal; it contains a geometrically tuned chamber with specific geometric forms that align with the direction of flow.
4. The unit is bi-directional.
5. Will become brittle and may deteriorate desired function if left exposed to the sun for an extended period of time.
6. Remove shower disperser head.
7. Install removed shower disperser head on to the units ½ inch male pipe threaded end.
8. Install the shower unit to ½ inch shower arm pipe where shower disperser head was originally removed from. Be aware of possible cross threading, unit should start on threads easily when it is lined up.
9. If shower head is too low it may be necessary to purchase an extension shower arm or adjustable shower adapter. A 10 inch shower arm riser is available on [www.bestwaterbalance.com](http://www.bestwaterbalance.com)
10. If a 10 inch riser shower arm is used remove the existing shower arm and install the 10 inch riser in its place and follow the same procedures installing the Structure Water Unit between the adapter and the shower disperser head.

See Spiritofwater.org for information on water spirit healing and techniques to enhance your structured water device.